



Avaya one-X™ Deskphone SIP for 9601 IP Telephone User Guide

16-603618
Issue 1
December 2010

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Note

Using a cell, mobile, or GSM phone, or a two-way radio in close proximity to an Avaya IP telephone might cause interference.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its Hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support Web site: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A

BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Avaya grants End User a license within the scope of the license types described below. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the Documentation or other materials available to End User. "Designated Processor" means a single stand-alone computing device. "Server" means a Designated Processor that hosts a software application to be accessed by multiple users. "Software" means the computer programs in object code, originally licensed by Avaya and ultimately utilized by End User, whether as stand-alone Products or pre-installed on Hardware. "Hardware" means the standard hardware originally sold by Avaya and ultimately utilized by End User.

License types

Designated System(s) License (DS). End User may install and use each copy of the Software on only one Designated Processor, unless a different number of Designated Processors is indicated in the Documentation or other materials available to End User. Avaya may require the Designated Processor(s) to be identified by type, serial number, feature key, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Shrinkwrap License (SR). Customer may install and use the Software in accordance with the terms and conditions of the applicable license agreements, such as "shrinkwrap" or "clickthrough" license accompanying or applicable to the Software ("Shrinkwrap License"). (see "Third-party Components" for more information).

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or Hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

Preventing Toll Fraud

"Toll fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud Intervention

If you suspect that you are being victimized by Toll Fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support Web site: <http://support.avaya.com>. Suspected security

vulnerabilities with Avaya products should be reported to Avaya by sending mail to: securityalerts@avaya.com.

Trademarks

All non-Avaya trademarks are the property of their respective owners, and “Linux” is a registered trademark of Linus Torvalds.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support Web site: <http://support.avaya.com>.

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your Product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://support.avaya.com>.

VCCI-Class B statement:

This is a Class B product based on the standard of the VCCI Council. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

Contents

Chapter 1: Introduction to the 9601 SIP Deskphone.....	9
Overview.....	9
Scrolling and navigation.....	11
About icons.....	12
Administrative messages.....	13
Telephone stand.....	13
Viewing Network Information.....	13
Chapter 2: Avaya Menu.....	15
Options & Settings.....	15
Setting the Phone Screen on calling.....	16
Setting the Phone Screen on ringing.....	17
Displaying call timers.....	17
Setting redial options.....	18
Configuring visual alerts.....	18
Setting the audio path.....	19
Setting dialing options.....	19
Setting up speed dialing.....	20
Personalizing button labels.....	20
Adjusting the contrast of the display.....	21
Changing the ring pattern.....	22
Setting a call pickup ring tone.....	22
Turning button click sounds on and off.....	23
Turning error tones on or off.....	23
Changing the language.....	24
Setting the time format.....	24
Turning automatic gain control on or off.....	25
Chapter 3: Answering a call.....	27
Sending an incoming call to voice mail.....	27
Ignoring an incoming call.....	28
Putting a call on hold.....	28
Muting a call.....	28
Transferring a call.....	29
Chapter 4: Making a call.....	31
Making an emergency call.....	31
Redialing a number.....	32
Speed dialing a person.....	32
Autodialing a pre-assigned number.....	32
Making a call using edit dialing.....	33
Calling a person from the contacts list.....	33
Calling a person from.....	34
Calling a person from the directory.....	34
Making a call using a “click to dial” link.....	35
Chapter 5: Forwarding calls.....	37
Send All Calls.....	37
Forwarding calls.....	37

Turning off call forwarding.....	38
Chapter 6: Conference calls.....	39
Setting up a conference call.....	39
Adding a person on hold to a conference call.....	39
Putting a conference call on hold.....	40
Dropping a person from a conference call.....	40
Chapter 7: Bridged call appearances.....	41
Answering a call on a bridged line.....	41
Joining a call on a bridged line.....	41
Making an outgoing call on a bridged line.....	41
Excluding others from bridging onto your call.....	42
Transferring a bridged call to its own voice mail.....	42
Chapter 8: Contacts.....	43
Searching for a contact.....	43
Viewing a contact's details.....	43
Adding a new contact.....	44
Editing a contact.....	45
Deleting a contact.....	45
Chapter 9: Call History.....	47
Viewing call history.....	47
Viewing call history details.....	47
Adding an entry from the call to your contacts list.....	48
Removing an entry from call history.....	48
Clearing all call history entries.....	48
Turning off call history.....	49
Chapter 10: Getting your messages.....	51
Logging into your voice mail.....	51
Chapter 11: About Features.....	53
Accessing the Features menu.....	53
Feature Table.....	53
Monitoring other extensions at a glance.....	55
Assigning labels to pre-assigned (Autodial) numbers.....	55
Setting up automatic call back.....	56
Making an auto intercom call.....	56
Call Forwarding when your line is busy or if you don't answer.....	57
Blocking your extension from displaying during calls.....	57
Displaying your extension on outgoing calls.....	58
Parking a call.....	58
Unparking a call.....	58
Picking up a call to another extension.....	59
Picking up a call to another call pickup group.....	59
Picking up a call from your pickup group.....	60
Calling someone in your intercom group.....	60
Tracing a malicious call.....	60
Recording a call.....	61
Making a priority call.....	61


Interrupting a call with a whisper page.....	62
Configuring simultaneous ringing for multiple telephones (EC500).....	62
Extending a call to your cell phone (EC500).....	63
Chapter 12: Limited access during failover.....	65
Chapter 13: About locking and logging in to and out of your telephone.....	67
Logging in to your telephone extension.....	67
Locking and unlocking your telephone.....	67
Logging out of your telephone extension.....	68
Index.....	69

Chapter 1: Introduction to the 9601 SIP Deskphone

Your deskphone provides many features, including a Phone screen to view and manage your calls, call History, a Contacts list, an integrated WML browser for the corporate directory, a menu of options and settings, and access to your voicemail. You can also attach up to three button modules to your telephone, to expand the available number of call appearances and features; multiple button modules must all be the same type and model.

Not all functions and features described in this user guide may be available on your deskphone. If you find that a function or feature is not available, please contact your system administrator.

Overview



The following table provides button/feature descriptions for the 9601 deskphone.

	Name	Description
1	Message Waiting Indicator	An illuminated red light in the upper-right corner of your phone indicates you have voicemail messages waiting. If visual alerting is enabled, this light flashes when you receive an incoming call.
2	Top Line	The Top Line shows status information such as the time and date, error indications and missed calls.
	Call Appearances	The number of lines available to make or receive calls (call appearances) depend on how your system is administered. Press the line button to initiate or answer a call.
3	Lines	The line buttons with integrated LEDs show which lines are in use and correspond to the lines on the display. Press the line button to select that line. Lines also indicate if a feature or system number (for example, an autodial number) is enabled or disabled in the Feature or System Numbers view.

	Name	Description
4 5	Softkeys and Softkey Labels	Use the softkeys to act on objects displayed on the screen. The softkey labels show you the action that each key produces.
6	Display More	Use the Display More key to scroll the selected line when the “>>” symbol appears.
7	Message	Press the Message button to connect directly to your voicemail system.
8	Navigation Arrows	Use the right and left navigation arrows to navigate between menus or to move the cursor during text input. Use the up and down navigation arrows to move from one line to another.
9	Phone	Press Phone to view and manage your calls.
10	Contacts	Press Contacts to view the entries in your Contacts list.
11	History	Press History to view the history of your outgoing, incoming, and missed calls.
12	Avaya Menu	Press Avaya Menu to configure options and settings, access the browser, log out, or view network information.
13	Volume	Press Volume to adjust the volume of the handset, headset, speaker, and ringer.
14	Mute	Press Mute to mute a call in progress. To take a call off mute, press Mute again.
15	Speaker	Press Speaker to use the speakerphone. To take a call off speakerphone, lift the handset.
16	Headset	Press Headset to use the headset if it is connected. Only HIS headset cords are compatible with your phone.

Scrolling and navigation

When navigating through the options and features on your telephone display, use the navigation arrows to scroll and buttons to select lines or options.













Use the up and down navigation arrows to scroll up or down through lists; holding either arrow for a few seconds produces a fast scroll. Use the right and left navigation arrows to move between the Phone screen and Features list or the Features list and System Numbers list, or to move the cursor right or left when entering text. Use the Display More key to scroll the selected line when the double chevron symbol (“>>”) appears in the display.

When you scroll to a line on the display, that line is selected. The softkey labels will change according to the options available for the selected line. The **OK** button is a shortcut for the default action. For example, when you select an entry in your contacts list, pressing the **OK** button places a call to that person.

You can also select a line or feature without scrolling by pressing the corresponding line button.

About icons

The icons in the following table indicate the state of a call, navigation choices, or the status of a contact whose presence you are tracking.

Icon	Description
	Missed call; a call was not answered or was forwarded to voice mail.
	Incoming call is alerting.
	Call is active.
	Call is on hold.
	Your calls are being forwarded.
	Conference is active.
	Conference is on hold.
	Use the Display More key to see more information on the selected line.
	The call in progress is muted.
	The ringer volume is off due to pressing - on the Volume button until the volume turns off. To reinstate volume, press + on the Volume button.
	Presence icon indicating this contact's phone is busy with the Send All Calls feature active. This icon also designates that a feature is not available at this point of a call.
	Icon indicating the telephone is not connected to its network and is operating in "failover" mode. Some features may not be available or work correctly. See Limited access during failover on page 65 for information.

Administrative messages

Your administrator can send important messages directly to your telephone, for example, notification of an early office closing due to inclement weather or information about an imminent service interruption.

These types of messages can take any of the following forms:

- a text message streaming across the top display line, accompanied by an audible alert,
- an audio message broadcasting through the Speaker (or the headset if that device is active),
- an “interrupt” screen notifying you that you are receiving an audio alert, with instructions for canceling the message or resuming your previous activity, such as continuing a call.

While receiving an audio message, you can switch between the Speaker, handset, and headset as desired, can terminate the pushed audio content by “going on-hook,” and can adjust the volume, as you normally would during a call.

Telephone stand

If your phone is in the upright position for wall mounting, reverse the tab located below the switchhook in the top ear piece pocket (on the front of the phone). This will keep the handset seated in the correct position. You will need a small screwdriver to lift this tab out.

Viewing Network Information

Your system administrator may ask you to check certain phone or network settings to investigate problems. Access network information from the Avaya Menu. Network Information has seven different viewing options: Audio parameters, IP (Internet Protocol) parameters, Quality of Service, Interfaces, .

Your system administrator will instruct you further as to which network information options and settings are needed.

Chapter 2: Avaya Menu

You can use the Avaya Menu to adjust and customize options and settings for your telephone, access additional Web-based applications, get information about your phone and network settings, and log out. When you press the Avaya Menu button, you see one of the following menus, depending on how your administrator has set up your system and on the applications available to you:

 **Note:**

The menus and sub-menus that appear depend on how your extension was administered. Some options or sub-menus may not be available. Contact your System Administrator if you have any questions.

- Options & Settings...
- Browser...
- Network Information...
- About Avaya one-X
- Log Out

Options & Settings lets you change your call settings, personalize button labels, adjust brightness and contrast, select your ringing pattern, set up favorites, assign speed dial entries, and more. See [Options & Settings](#) on page 15 for more information.

Network Information shows a summary of network-related parameters for your phone and provides diagnostic information. See [Viewing Network Information](#) on page 13 for information. If your administrator has set up Web applications, this option appears under the Phone Settings menu instead.

About Avaya one-X provides the release number of your telephone software.

Log Out lets you sign off the phone, to protect your settings or to allow another user to log in.

Options & Settings

- Call Settings...
- Assign Speed Dial Entries...
- Application Settings...
- Screen & Sound Options...

- Language and Region...
- Advanced Options...

Call Settings includes choices for automatically displaying the Phone screen when you get an incoming call or when you place a call, turning call timers on or off, controlling how Redial works, turning Visual Alerting on or off, and more.

Assign Speed Dial Entries lets you assign speed dial numbers to up to ten contacts, so you a long press a single digit initiates a call to that person. See [Setting up speed dialing](#) on page 20 for more information.

Assign Favorites Entries lets you build a list of up to nine favorite contacts or features. See [Setting up favorites](#) for more information.

Application Settings includes choices for personalizing button labels, turning call on or off and including bridged calls in your call History.

Screen & Sound options includes choices for adjusting your phone's brightness and contrast, ring pattern, background logos, and button clicks and tones.

Advanced Options includes choices for integrating other applications like Microsoft® Exchange Server with your phone. You can also set AGC (Automatic Gain Control) for your headset, handset, and/or speaker audio.

Network Information has a sub-menu with seven different viewing options: Audio parameters, IP (Internet Protocol) parameters, Quality of Service, Interfaces, and Miscellaneous, Audio parameters, IP (Internet Protocol) parameters, Quality of Service, Interfaces, 802.1X Parameters, Miscellaneous, and Diagnostics. Your system administrator may ask you to use this option to check certain phone or network settings to investigate problems.

Setting the Phone Screen on calling

Set Phone Screen on Calling to Yes to automatically display the Phone screen when you place a call.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Call Settings.
 5. Press **Select** or **OK**.
 6. Select Phone Screen on Calling.

7. Press **Change** or **OK** or use the right or left navigation arrows to set the option to Yes or No, depending on the current setting.
 8. Press **Save**.
-

Setting the Phone Screen on ringing

Set Phone Screen on Ringing to Yes to automatically display the Phone screen when you get an incoming call.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Call Settings.
 5. Press **Select** or **OK**.
 6. Select Phone Screen on Ringing.
 7. Press **Change** or **OK** or use the right or left navigation arrows to set the option to Yes or No.
 8. Press **Save**.
-

Displaying call timers

You can set your call settings to display the duration of calls. You can turn the call timer display on or off.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Call Settings.
 5. Press **Select** or **OK**.
 6. Select Display Call Timers.

7. Press **Change** or **OK** or use the **Left/Right** arrows to change the setting.
 8. Press **Save**.
-

Setting redial options

You can set Redial to dial the last number you dialed or to display a list of the last numbers you dialed.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Call Settings.
 5. Press **Select** or **OK**.
 6. Select Redial.
 7. Press **Change** or **OK** or the **Right/Left Arrows** to toggle between One Number and List.
 8. Press **Save**.
-

Configuring visual alerts

When the Visual Alerting option is turned on, incoming calls cause the LED in the top right corner of the phone to flash. You can turn Visual Alerting on or off.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Select Call Settings.
 4. Select Visual Alerting.
 5. Press **Change** or **OK** or use the **Right/Left** arrows to turn Visual Alerting on or off.
-

Setting the audio path

You can set your phone to go off-hook on the Speaker or the Headset when you make an on-hook call. If your system administrator has set up auto-answer, incoming calls are also answered on the default audio path you designate here.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings or Phone Settings.
 3. Press **Select** or **OK**.
 4. Select Call Settings.
 5. Press **Select** or **OK**.
 6. Select Audio Path.
 7. Press **Change** or **OK** or use the **Right/Left** arrows to change the Speaker or Headset setting.
 8. Press **Save**.
-

Setting dialing options

Your phone has two dialing options. You can dial as you normally would, for example, pick up the handset, get a dial tone, and dial the number you want (on-hook dialing). Or, you can set "edit dialing" which mimics how you dial a call on a cell phone - you can enter all or part of the number, backspace to correct a digit if needed, and when ready, initiate the dialing process using a softkey.

 **Note:**

Edit dialing may not be available to you, depending on how your system is administered.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Call Settings.
 5. Press **Select** or **OK**.
 6. Select Dialing options.

If your telephone does not display this option, your administrator has not made this feature available.

7. Press **Change** or **OK** or the **Right/Left Arrows** to toggle between On-hook and Editable.

When on-hook dialing is in effect, dialpad (edit dial) searches are not available.

8. Press **Save**.
-

Setting up speed dialing

You can assign speed dial numbers to up to 10 people in your contact list. Then when you want to call a speed dial contact, simply press the number you've assigned to that person.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Scroll to Assign Speed Dial Entries....

If your telephone does not display the Assign Speed Dial option, your administrator has not made this feature available.

5. Press **Select** or **OK**.
 6. To un-assign an existing speed dial contact, scroll to the line you want to un-assign and **Clear**. Proceed to the next step to reassign that number.
 7. To add a speed dial contact, scroll to the first unassigned line and press the **Assign** softkey .
 8. Scroll to the contact you want to assign and **Select** .
 9. Select the telephone number you want to assign.
 10. Press the **Select** softkey or the **OK** button.
-

Personalizing button labels

You can change the labels that are displayed for your extensions, features, and system numbers or speed dial buttons. For example, you can change the label for your extension to "My Line." You cannot edit Autodial buttons labels using this procedure. For information, see [Assigning labels to pre-assigned \(Autodial\) numbers](#) on page 55. If you have a button module attached to your deskphone, you can change any of those labels as well; for example, you can change a Help Desk extension to read "Help Desk."

**Note:**

The 9601SIP phone does not support button modules

1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Select Application Settings.
 4. Select Personalize Labels...
 5. Press **Select** or **OK**.
 6. Select the label you want to edit.
If the label you want to edit is on the Features menu, scroll right to access the Features menu, and select the label you want to edit. If the label you want to edit is on the System Numbers menu, scroll right twice to access the System Numbers menu and select the label you want to personalize.
 7. Press **Edit**.
 8. Edit the label using up to 13 characters.
Press **More** then **Clear** to clear all text fields and start over.
 9. Press **Save** or **OK**.
 10. You may revert back to the default button labels by selecting **Options & Settings** > **Application Settings** > **Restore Default Button Labels** and pressing **Default**.
-

Adjusting the contrast of the display

1. Press **Avaya Menu**.
2. Select Options & Settings or Phone Settings.
3. Press **Select** or **OK**.
4. Select Screen & Sound Options.
5. Press **Select** or **OK**.
6. Select Contrast.
7. Press **Change** or **OK**.

8. Scroll to the right or left to adjust the contrast.
 9. Press **Save** or **OK**.
-

Changing the ring pattern

1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Screen & Sound Options.
 5. Press **Select** or **OK**.
 6. Scroll to and select Personalized Ringing.
The ring tone currently selected displays on the prompt line and a list of all eight ring tones within that category displays with a checkmark next to the pattern currently selected. The first softkey indicates the other ring tone category, to allow you to switch between categories.
 7. Press **Change** to move from one ring tone to the next.
 8. Repeat the last step until you find the ring pattern you want.
 9. Press **Save** to make it your ring pattern.
-

Setting a call pickup ring tone

1. Press **Avaya Menu**.
2. Select Options & Settings...
3. Select Screen & Sound Options.
4. Press **Select** or **OK**.
5. Select Call Pickup Ring Type.
6. Press **Change** or **OK** or use the **Right/Left Arrows** to toggle from one ring tone/number to another. Each tone sounds briefly as you move to it.
7. If desired, press **Play** or **OK** to listen to the ring tone.

8. Repeat the last two steps until you find the ring tone you want for calls within your pickup group.
 9. Press **Save** to make it your call pickup ring tone.
-

Turning button click sounds on and off

1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Screen & Sound Options.
 5. Press **Select** or **OK**.
 6. Select Button Clicks.
 7. Press **Change** or **OK** or use the **Right/Left** arrows to turn sounds on or off.
 8. Press **Save**.
-

Turning error tones on or off

Your telephone beeps if you make a mistake or take an action that is not allowed. If you do not want to hear error beeps, set your error tone to Off.

1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Screen & Sound Options.
 5. Press **Select** or **OK**.
 6. Select Error Tones.
 7. Press **Change** or **OK** or use the **Right/Left** arrows to turn error tones on or off.
 8. Press **Save**.
-

Changing the language

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Language & Region...
 5. Press **Select** or **OK**.
 6. Select Language....
 7. Select a display language.
 8. Press **Select** or **OK**.
 9. Press **Yes** to confirm the selected language.
-

Setting the time format

You can change the way the time displays on your screen. The time format is either 12 or 24 hours.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Language & Region...
 5. Press **Select** or **OK**.
 6. Select Time Format.
 7. Press **Select** or **OK**.
 8. Press **Change** or **OK** or use the **Right/Left** arrows to change the time format.
 9. Press **Save**.
-

Turning automatic gain control on or off

-
1. Press **Avaya Menu**.
 2. Select Options & Settings...
 3. Press **Select** or **OK**.
 4. Select Advanced Options...
 5. Press **Select** or **OK**.
 6. Select Automatic Gain Control...
 7. Press **Select** or **OK**.
 8. Select the device (Handset, Headset, or Speaker) for which you want to turn AGC on or off.
 9. Press **Change** or **OK** to turn AGC on or off.
 10. Press **Save**.
-

Chapter 3: Answering a call

When you receive an incoming call, the incoming call is usually selected automatically. However, if you are already on a call or if you receive more than one incoming call at a time, you may need to select the call you want to answer manually. If you do not have the Go to Phone on Ringing option enabled, you must press **Phone** to choose a line or view call options.

If you do not have the Go to Phone Screen on Ringing option enabled and if the Phone screen is not displayed, incoming calls display on the top line of the screen. You can touch the line to answer the call or press the Phone button to view the Phone screen.

Answer an incoming call in one of the following ways:

- If you are not on another call, lift the handset, or press **Speaker** to answer using the speakerphone, or press **Headset** to answer using the headset.
- If you are on another call, from the Phone screen, scroll to the line with the incoming call and press **Answer** or **OK**.
- If you are on another call and the telephone does not automatically display the incoming call, from the Phone screen scroll to the line with the incoming call and press **Answer** or **OK**. If you are on another call and the telephone does automatically display the incoming call, you can press **Answer** to automatically put the first call on Hold when you answer the new call. Alternately, you can press **Ignore** to automatically drop the first call when you answer the new call.

To automatically display the Phone screen whenever you receive an incoming call, set the Go to Phone Screen on Ringing option to Yes (see [Setting the Phone Screen on ringing](#) on page 17).

 **Note:**

To automatically display the Phone screen whenever you receive an incoming call, set the Phone Screen on Ringing option to Yes (see [Setting the Phone Screen on ringing](#) on page 17).

Sending an incoming call to voice mail

Press **To Vmail** to send an incoming call directly to voicemail.

If your telephone does not display a **To Vmail** softkey, your administrator has not made this feature available.

Ignoring an incoming call

Press **Ignore** to turn off the ringer for an incoming call

Putting a call on hold

-
1. Press **Phone** to view the main Phone screen, if necessary.
 2. If you are not active on the line you want to put on hold, select that line.
 3. Press **Hold**.

 **Note:**

A hold timer may display when you put a call on hold. For more information, see [Displaying call timers](#) on page 17.

4. Press **Resume** or the line button of the held call to retrieve the call. Your system administrator may have administered the Hold Recall feature, which alerts you visually and with a priority ring to remind you of a held call after a certain period of time.
-

Muting a call

When the call is muted, the Mute button light is on and the top line displays the Mute icon.

-
1. Press **Mute** during a call so that the other person cannot hear you.
 2. Press **Mute** again to unmute the call.
-

Transferring a call

-
1. From the Phone screen, if the call to be transferred is not already active (highlighted), select the line on which the call to be transferred appears.
 2. Press **Transfer**.
 3. Dial the telephone number, or call the person from the Contacts list, or call the person from the Call Log History list.
 4. If unattended transfers have been administered, you can hang up now if you do not want to announce the call. Otherwise, press **Complete** or **OK**

 **Note:**

Unanswered transfers may be returned to your telephone as a recalled transfer. In this case, you hear a priority ring and see the display message `Return` next to the call.

Answering a call

Chapter 4: Making a call

If you are not on a call, simply dial the number you want to call. Use the Phone screen to view and manage calls. Press **Phone** to view the main Phone screen at any time. When the Phone screen is displayed, press **Phone** to move to the top of the call appearance list.

Lift the handset, or press **Speaker** or **Headset** (if applicable) or a line button for an available line.

Making an emergency call

You do not have to be logged in to make an emergency call. If emergency calling was set up by your system administrator, the Phone screen has an Emergency softkey to immediately connect you with a preset emergency services number.

 **Important:**

During telephone failover (switching between telephone system servers during a system failure) the Emergency softkey may not be available until your telephone is connected with an alternate server, usually within several seconds.

-
1. Press the **Emerg.** softkey. If you do not see an **Emerg.** softkey, pick up the handset or press the **Phone** button, then press the **Emerg.** softkey.
 2. If the telephone prompts "Do you want to make an emergency call?" press the **Yes** softkey.
Some phone systems will call back to confirm the emergency status. The phone automatically answers the incoming call on the Speaker and displays "Emergency Call in Progress".
 3. To end the emergency call, press the **End Call** softkey or press the **Speaker** button.
-

Redialing a number

1. From the Phone screen, press **Redial**.

The last number will be redialed or you will see a list of the most recent numbers that you have dialed, from which you can select one to redial. See [Setting redial options](#) on page 18 for information on redial settings.



The last number dialed and redial list are cleared if the Outgoing Call Log is cleared.

2. If you are working with a redial list, scroll to the number you want to call and press **Call** or **OK**.

Your system administrator can disable Redial functionality.

Speed dialing a person

On the Phone screen, press and briefly hold the dialpad key assigned to the person you want to call. Or, if speed dial numbers are assigned to a button module attached to your phone, press the button assigned to the person you want to call.

To assign speed dial numbers to up to 10 contacts, see [Setting up speed dialing](#) on page 20

Autodialing a pre-assigned number

Your system administrator may set up frequently called numbers such as Information Technology or the Help Desk as Autodial numbers, so you can dial them with one touch.

Making a call using edit dialing

Prerequisites

Your system administrator has to authorize this function. To set up edit dialing, see .

Edit dialing works just like making a call on your cell phone - just start entering the number without hearing a dial tone. Using softkeys, you can change the number/character format or backspace to "edit" the number before actually dialing it. Using the Bksp softkey, you can backspace to "edit" the number before actually dialing it.

- _____
1. From the Phone screen, enter the number you want to call.
 2. To edit the number press the **Bksp** softkey to erase the previous character, one character at a time. To change the character format press the **123/abc** softkey.
 3. Press **Call** or **OK**.
- _____

Calling a person from the contacts list

You can call someone in your Contacts list by touching the name in the list. You can find a name by scrolling to it, or by using the search box. Use the dialpad keys to enter the first few letters of the name and the screen will scroll to the first match in your list.

- _____
1. Press the **Contacts** button.
 2. Select the person or number you want to call.
 3. Locate the contact you want by starting to type the person's name as it is listed. For example, if you added John Smith to your Contacts List as "Smith, John" you would start typing his last name rather than his first name. Each time you press the dialpad, the list display shifts to match your input. Alternately, you can scroll up or down to locate the contact.
 4. Press **Call** , **OK** or the **Line Appearance** button next to the number.
- _____

Calling a person from

-
1. Press the button.
 2. Scroll to the left or right to view a separate list of all, un-answered, answered, or outgoing calls.
 3. Scroll up or down to select the person or number you want to call.
 4. Select the person or number you want to call.
-

Calling a person from the directory

If your administrator has set up a company directory you can use the Contacts button to search through the directory, then call the person you found.

 **Note:**

Use the Contacts button on the phone to initiate either a directory search as described here or to find a contact on your personal Contacts list. To locate a person on your Contacts list, see [Searching for a contact](#) on page 43.

-
1. Press **Contacts**.
 2. Press **More**.
 3. Press **Search**.
 4. Enter the person's full or partial first name if desired. To enter all or part of the last name only, skip this step and the next and scroll down to the Last Name field.
 5. Press **OK**.
 6. Enter the person's full or partial last name.
 7. Press **Search** or the **OK** button to start searching the directory.
 8. When the person you want displays, press **Call** to call the person.
-

Making a call using a “click to dial” link

-
1. Select the line with the link for the person or number you want to call.
 2. Press the line button corresponding to the line with the link or press **OK**.
The deskphone initiates a call to the person or number associated with the click to dial link.
-

Making a call

Chapter 5: Forwarding calls

You can forward your incoming calls to another number or to voicemail.

Send All Calls

When Send All Calls (SAC) is on, your incoming calls go directly to a predefined coverage number, typically your voicemail. Incoming calls ring once at your extension and then go directly to a number which is set by your system administrator. If the SAC feature is administered on your phone, a Send All softkey appears on the Phone screen for idle calls. Pressing Send All turns Send All Calls on. If it is already on, pressing Send All turns it off. You can also turn Send All Calls on or off by using the telephone Features list.

-
1. From the Phone screen, scroll right to access the Features menu.
 2. Select SendAllCalls.
 3. Press **OK** or press the line button on which Send All Calls appears to turn Send All Calls on or off.
-

Forwarding calls

Several forwarding features may be available so you can set a number to which your calls will be forwarded, or turn off call forwarding if it is already on.

-
1. From the Phone screen, scroll right to access the Features menu.
 2. Select Call Fwd.
 3. Enter the number to which you want to forward your calls as the destination, then press **Enter** or **OK**.
After you enter the forwarding number, you hear a confirmation tone.
 4. Press **OK** or the Line button to turn the call forwarding feature off if it is already on.
-

Turning off call forwarding

-
1. From the Phone screen, scroll right to access the Features menu
 2. Scroll down to the active Call Forward button.
 3. Press **OK**
When you turn off the Call Forwarding feature, you hear a confirmation tone.
-

Chapter 6: Conference calls

You can use conference calls to speak with up to five people in different locations on the same call . Additional conferencing options may be available through Expanded Meet-Me Conferencing. Contact your system administrator for more information about this feature.

Setting up a conference call

-
1. From the Phone screen, select your active call.
 2. Press **Conf**.
 3. Dial the telephone number, or call the person from the Contacts list, or call the person from the History list.
 4. When the person answers, press **Join** or **OK** to add the person to the existing call.
 5. Press **Add** and repeat these steps to add another person to the conference call.
 6. Press **Drop** at any time to drop the last person added to the conference call.
-

Adding a person on hold to a conference call

-
1. From the Phone screen, select your active call.
 2. Press **Conf**, or **Add** if you are already in a conference.
 3. Select the call on hold that you want to add to the conference.
 4. Press **Resume** to take the call off hold.
 5. Press **Join** or **Conf** to add the person to the conference call.
-

Putting a conference call on hold

When you put a conference call on hold, the other parties can still talk to each other.

-
1. Press **Hold** during a conference call.
 2. Press **Resume** or **OK** to resume the conference call.
-

Dropping a person from a conference call

This feature is not available on all systems.

-
1. From the Phone screen, select your active call.
 2. Press **Details**.
 3. Select the person you want to drop.
 4. Press **Drop**.
-

Chapter 7: Bridged call appearances

Your phone may show one or more bridged call appearances on the display screen in addition to your own call appearances. A bridged call appearance typically belongs to someone else, but bridging allows you to see if that call appearance is in use, answer calls on that appearance, or join a call in progress on that call appearance from your telephone. You can also make outgoing calls on a bridged call appearance when it is not in use.

Answering a call on a bridged line

Answering a call on a bridged line is basically the same as a call on a primary line.

-
1. Select the bridged call that you want to answer.
The ringing line will typically be selected automatically. If you are on another call when a call comes in to a bridged line, you have to select the ringing line (just like for an incoming call to a primary line).
 2. Press **Answer**
-

Joining a call on a bridged line

-
1. Select the bridged call in progress that you want to join.
 2. Press **Bridge**.
-

Making an outgoing call on a bridged line

When you make a call on a bridged line, you are using another person's line. The caller ID may show the call as coming from you or coming from the person whose line you are using. If

you have any questions about how the name or extension displays to the person you are calling, contact your system administrator.

-
1. Select the bridged line you want to use.
 2. Press **OK** to get a dial tone.
 3. Dial the telephone number, or call the person from the Contacts list, or call the person from the History list.
-

Excluding others from bridging onto your call

Use the Exclusion feature to prevent others who are bridged to your extension from bridging onto a specific call. You can activate exclusion only during an active call.

-
1. During an active call, scroll right from the Phone screen to access the Features menu.
 2. Scroll down to Exclusion and press **OK** or just press the corresponding line button. When you activate Exclusion during a call, all parties except you and the calling/called party are dropped from the call.
-

Transferring a bridged call to its own voice mail

Use the Transfer to Voice Mail feature to transfer a call you took on a bridged line to its voice mail.

-
1. During an active bridged call, scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Transfer to Voice Mail.
 3. Press **OK** or **Enter** to transfer the bridged call to its respective voice mail system.
-

Chapter 8: Contacts

Searching for a contact

You can jump to a certain group of letters in your Contacts list by pressing the associated dial pad button. For example, if you press 3, the Contacts list might display entries starting with D, E, F, or 3 depending on how you set up your contacts. With each successive dialpad key press, the Contacts list “drills down” to display matching entries.

 **Note:**

On hook dialing must be disabled to allow this type of Contact search; to enable/disable on-hook dialing, see [Setting dialing options](#) on page 19.

-
1. Press **Contacts**.
 2. Using the dialpad, start typing the name for which you want to search.
Keep in mind how your Contact list is set up. If you set up your contacts as “Last Name, First Name” start typing the letters of the last name. If you have set up your Contacts using a different scheme, type the most likely letter(s) that would match the contact you want to find.
 3. Press **Call** or the **Line Appearance** button to call the person or **More** then **Edit** to edit contact information.

Next steps

If your administrator has set up a corporate contact list or database, you can extend a search. For information, see [Extended searching](#).

Viewing a contact's details

-
1. Press **Contacts**.
 2. Select the contact you want to view.

3. Press **Details** to see the information available for that contact.
Selecting Details is the only way to dial a second or third number for a contact.
 4. Press the appropriate softkey to call or edit this contact, delete this contact, or return to the Contacts screen.
-

Adding a new contact

You can add up to six numbers for a contact. Selecting "handle" as a type allows you to track the contact's telephone presence, for example, not logged in, logged in, in use, or sending all calls to another number.

-
1. Press **Contacts**.
 2. Press **New**.
 3. Enter the first and last name using the dialpad.
 - a. Press the number key that corresponds to the letter or number you want to enter until the letter or number is displayed.
 - b. Pause before entering the next character if the characters are on the same key.
 - c. To enter a space, press **0**.
 - d. Enter remaining letters or numbers.
 - e. Press **Bksp** to delete the last character.

 **Note:**

If you want to remove a letter, number, space, or symbol that is in the middle of the text you entered, use the left and right navigation arrows to place your cursor after the character you want to remove. Once your cursor is in the correct position, press **Bksp** to remove the character to the left of the cursor.

4. Select the next field.
5. Enter the telephone number and press **Primary** if applicable.
The primary number is the one that will always display without having to go into contact details.
6. Select the next field.
7. Select the type of number entered (work, mobile, home, handle).
If you select handle, provide a value that represents the extension number, an "at" @ symbol, and the company name, for example, 21234@avaya.com. You can then determine the contact's presence based on handle icons that appear next to this person's name/number.

8. If you have another number for this contact, scroll down and repeat Steps 5 - 7.
You can add up to five additional numbers for this contact, but you can designate only one number as primary.
 9. Press **Save** or **OK**.
-

Editing a contact

-
1. Press **Contacts**.
 2. Search for and select the contact you want to edit.
 3. Press **More > Edit**.
 4. Choose the field you want to edit.
 5. Use the dialpad and softkeys to make changes to the contact information.
 6. Press **Save** or **OK**.
-

Deleting a contact

-
1. Press **Contacts**.
 2. Select the contact you want to delete.
 3. Press **More > Delete**.
 4. Press **Yes** to confirm or **No** to cancel.
-

Chapter 9: Call History

The History screen provides a list of recent calls, with information about call disposition (missed, answered, or outgoing) and with caller name and number (where available), call time, and call duration. Call History also shows bridged calls. If you are a member of a call pickup group, any calls you picked up for another person or that you missed and were answered by someone else in your pickup group are shown with a Forwarding icon to allow you to review details of that type of call. When you have one or more missed calls, the History button lights and the Missed Calls icon and the number of missed calls display on the top line. To call a person listed in your Call History, see [Calling a person from](#) on page 34.

Viewing call history

-
1. Press **History**.

You can go to the top of the list by pressing **History** again.

2. Scroll to the right or left to view separate lists of answered, outgoing, or missed calls. Scroll to the right or left to view separate lists of all, answered, outgoing, or missed calls.



Note:

When contacts whose presence you have set up to track have called you, the applicable presence icon displays along with their call information. See [About icons](#) for a description of presence icons.

3. Scroll up or down to view the entries on the list.
-

Viewing call history details

-
1. Press **History**.
 2. Select the number you want to view.
 3. Press **Details**.

If you are logging bridged calls as well as your own, bridged call details are identified by either CALL FOR: (calls made to the bridged line) or CALLED FROM: (calls made from the bridged line) preceding the applicable number. To log/not log bridged calls, see [Turning off call history](#).

4. Press **Back** to return to the list view.
-

Adding an entry from the call to your contacts list

-
- 1.
 2. Select the number you want to add to your Contacts list.
 3. Press **+Contact**.
 - 4.
 5. Edit the name and telephone number, if necessary.
 6. Press **Save**.
-

Removing an entry from call history

-
1. Press **History**.
 2. Select the number you want to delete.
 3. Press **More** then **Delete**.
 4. Press **Delete** or **OK** to confirm, or press **Cancel** if you do not want to delete it.
-

Clearing all call history entries

Clearing all entries from the call history deletes all of the entries for the specific list you are viewing. For example, if you are viewing the Outgoing calls list, only outgoing calls are deleted.

-
1. Press **History**.
 2. Select the list you want to delete.
 3. Press **Clear All** to delete all of the entries in the list you are viewing.
 4. Press **Yes** to confirm.
-

Turning off call history

You can turn History on or off. If you have bridged call appearances on your phone, you can choose whether or not to include calls to your bridged lines in your call history log.

-
1. Press **Avaya Menu**.
 2. Select Options & Settings or Phone Settings.
 3. Select Options & Settings...
 4. Press **Select** or **OK**.
 5. Select Application Settings.
 6. Press **Select** or **OK**.
 7. Select the type of call logging you want to turn off.
To turn off logging your calls, select History. To turn logging of bridged lines on or off, select Log Bridged Calls.
 8. Press **Change** or **OK** to turn call history logging on or off.
 9. Press **Save**.
-

Call History

Chapter 10: Getting your messages

Press the **Message** button to connect directly to your voicemail system.

The lighted Message button and a red light on the upper right-hand corner of your telephone indicate when you have messages waiting. Your messages are an administered function. Contact your system administrator with any questions.

Logging into your voice mail

-
1. To log in to your voice mail, press the **Message** button.
 2. Follow the voice prompts from your voice mail system.
-


Chapter 11: About Features

Your administrator may have set up your telephone so that it presents the Features as described in this chapter together on one screen with your call appearances; if so, the features work as described in this chapter, but they do not appear on a separate Features menu. You can use Send All Calls and Call Forward to have your incoming calls sent to other numbers. When set to “on,” EC500 allows calls to your desk phone to also be sent to your cell phone. Other features like Call Park, Call Pickup Extended, and Transfer to Voicemail may be available on your Features menu. The particular features available to you depend on what your administrator has assigned to your phone.

In addition to the Features menu, your administrator may also place selected features on softkeys on the call appearance (Phone) screen. For more information about what features and options are available for your extension, contact your system administrator.

Accessing the Features menu

From the Phone screen, scroll right to access the Features menu.

The icon next to a feature indicates the feature is available, the icon next to a feature indicates the feature is activated, and the  icon next to a feature indicates the feature is not available. For models with LEDs, the LED next to the feature name indicates if the feature is currently on or off. If the light is on, the feature is on.

To return to the main Phone screen, press **Phone** or scroll to the left. Scrolling right displays the System Numbers menu screen; scrolling right again displays the Phone screen.

Feature Table

Feature names are often abbreviated to fit your deskphone or button module display area. Use this table as a cross-reference to standard feature names and their corresponding common abbreviations. Depending on how your system is administered, not all features shown here may be available to you. For detailed information about a feature, click its link in the Feature Name column.

Feature Name	Common Abbreviation
Autodialing a pre-assigned number on page 32	Phone number or extension set up by your administrator as an auto-dial number, followed by a telephone icon or “Autodial”
Making an auto intercom call on page 56	Auto Icom; Auto In
Setting up automatic call back on page 56	Auto Callback
Forwarding calls on page 37	Cfrwd or CFrwd with a third-party's extension if applicable
Call Forwarding when your line is busy or if you don't answer on page 57	CFBDA
Parking a call on page 58	Call park
Picking up a call from your pickup group on page 60	Call pickup
Blocking your extension from displaying during calls on page 57	CPN Block
Displaying your extension on outgoing calls on page 58	CPN Unblock
Calling someone in your intercom group on page 60	Dial Icom
Picking up a call to another extension on page 59	Dir Pickup
Configuring simultaneous ringing for multiple telephones (EC500) on page 62	EC500
Excluding others from bridging onto your call on page 42	Exclusion
Extending a call to your cell phone (EC500) on page 63	Extend Call
Picking up a call to another call pickup group on page 59	Ext Pickup
Tracing a malicious call on page 60	MCT Act
Recording a call on page 61	Audix Record
Making a priority call on page 61	Priority Call

Feature Name	Common Abbreviation
Send All Calls on page 37	SendAllCalls, SAC, or SAC with a third-party's extension, if applicable
Interrupting a call with a whisper page on page 62	Whisper Act

 **Note:**

If you have personalized labels for any of the features available to you, the personalized label displays instead of the feature abbreviations shown here.

Monitoring other extensions at a glance

If your job requires that you cover or monitor phones for others, your system administrator may set up “busy indicators” so that you can see whether an extension you cover is idle or busy at a glance. Extensions you can monitor with busy indicators show the word “Busy” next to the extension number.

-
1. From the Phone screen, use the right arrow key to scroll to the Features screen.
 2. Press **System Numbers** to display the System Numbers menu.
 3. If necessary, scroll to the line button for the extension you want to check. If that extension is in use, the busy indicator displays next to the word Busy.
 4. To call a monitored extension, scroll to the applicable line and press the line button associated with that extension.
-

Assigning labels to pre-assigned (Autodial) numbers

Autodial numbers are frequently-called numbers in your office or organization, for example, a Help desk number. Your system administrator sets up Autodial numbers, but you can assign and edit their labels. The administrator might just allot a specific button to be an Autodial number, but leave the number itself blank; in this case you can add the number yourself.

-
1. From the Phone screen, scroll right twice to display the System Numbers menu.
 2. Scroll to the line to which you want to assign a label or number.
Some labels are not editable. If you can't scroll to a certain line or hear an error tone when you press the line button, you cannot edit that label.

3. Press **Edit** or the **OK** button.
 4. Use the dialpad to enter the label text or the Autodial number.
 5. Press Save.
-

Setting up automatic call back

When an extension you call is busy, use Automatic Call Back to receive a return call automatically, as soon as that extension is free.

-
1. After calling an extension and while receiving a busy signal, scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Auto Callback and press **OK** or just press the corresponding line button.
 3. When you hang up the callback call, the feature deactivates automatically.
-

Making an auto intercom call

Use the Auto-Intercom feature to call a specific extension or intercom group.

-
1. Before dialing, scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Auto Icom and press **OK** or just press the corresponding line button.

Two numbers display with the Auto Icom feature, for example “Auto icom 2 3”. The first number denotes the intercom group number for the Dial Intercom feature. The next number denotes the extension your administrator has predefined as your automatic intercom destination extension.
 3. Press the number(s) that corresponds to the destination extension.
 4. Press **Enter** or **OK** to activate the intercom call to that extension, where the call appearance identifies the incoming call with your name followed by ICOM.
-

Call Forwarding when your line is busy or if you don't answer

The Call Forward Busy/No Answer feature allows you to set a number to which your calls will be forwarded when your line is busy or when you don't answer a call. You must enter the telephone number where the calls will be forwarded each time you use this feature.

-
1. If your deskphone is a 9601, 9608 or 9620, from the Phone screen, scroll right to access the Features menu.
 2. Select CFrwdCall Fwd Busy/No Ans.
 3. Enter the number you want to forward your calls to.
After you enter the forwarding number, you hear a confirmation tone.
 4. Press **OK** to turn call forwarding off if it is already on.
-

Blocking your extension from displaying during calls

You can override the system (default) setting to display your extension on outgoing calls. Use the Calling Party Number Blocking feature to prevent your number from displaying.

-
1. From the Phone screen, scroll right to access the Features menu.
 2. Select **CPN Block**.
To stop calling party number blocking, see [Displaying your extension on outgoing calls](#) on page 58.
 3. Press **OK**.
 4. Enter the extension number you do not want the called party to see.
 5. Press **Enter** or **OK** to start calling party number blocking.
-

Displaying your extension on outgoing calls

If you used the CPN Block feature to block your extension's display on calls you make, you can change it back using CPN Unblock. CPN (Calling Party Number) Unblock lets parties you call see your extension.

-
1. From the Phone screen, scroll right to access the Features menu.
 2. Select **CPN Unblock**.
To set up calling party number blocking, see [Blocking your extension from displaying during calls](#) on page 57.
 3. Press **OK**.
 4. Enter your extension number.
 5. Press **Enter** or **OK** to stop calling party number blocking.
-

Parking a call

Use the Call Park feature to answer a held call at another extension if you are part of a telephone coverage or hunt group. For example, if you need to go to another location to verify some information, you can park your current call and answer it at another location within your group.

-
1. During an active call, scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Call Park and press **OK** or just press the corresponding line button.
 3. At the other telephone, press the Call Park line/feature button to unpark the call.
-

Unparking a call

Use the Call Unpark feature to release a call from the extension at which it was parked, when the extension is part of a coverage or hunt group.

-
1. From the Phone screen, scroll right to access the Features menu.
 2. If necessary, scroll down to Call Unpark and press **OK** or just press the corresponding line button.
 3. Enter the original extension from which the call was parked.
 4. Press **Enter** or **OK** to release (unpark) the call.
-

Picking up a call to another extension

When your administrator has set up this feature, you can answer a call ringing at another extension without having to be a member of a "pickup group."

-
1. Scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Directed Call Pickup and press **OK** or just press the corresponding line button .
 3. Answer the call as you normally would.
-

Picking up a call to another call pickup group

When your administrator has set up this feature, you can answer a call ringing at a phone in a call pickup group other than your own.

-
1. Scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Extended Call Pickup and press **OK** or just press the corresponding line button.
 3. Answer the call as you normally would.
-

Picking up a call from your pickup group

When your administrator has set up your phone as part of a "pickup group" use the Call Pickup feature to answer any other phone in the group.

-
1. From the Phone screen, scroll right to access the Features menu.
 2. If necessary, scroll down to Call Pickup and press **OK** or just press the corresponding line button.
 3. Answer the call as you normally would.
-

Calling someone in your intercom group

If your system administrator has set up an intercom group, you can call anyone in that group by pressing a few numbers.

-
1. Before dialing, scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Dial Icom and press **OK** or just press the corresponding line button.
The intercom group number shows next to the Dial Intercom feature and the next denotes the extension your administrator has predefined as your automatic intercom destination extension.
 3. Press the number(s) that corresponds to the destination extension.
 4. Press **Enter** or **OK** to activate the intercom call to that extension, where the call appearance identifies the incoming call with your name followed by ICOM.
-

Tracing a malicious call

Use the Malicious Call Trace (MCT) feature to trace a malicious call. Activating MCT alerts a controller to begin call tracing and provide information for reporting this call. This feature is available only if your administrator has set up the phone system to trace and track malicious calls and there is an attendant or controlling user to oversee the trace.

-
1. During an active call, scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to MCT and the corresponding line button to start the trace. An alerting tone and/or flashing LED signifies the trace is active. Hanging up deactivates MCT.

 **Important:**

Some countries, states, and localities have laws that determine if and under what circumstances you can use Malicious Call Trace (MCT) Before using the MCT feature, you must understand and comply with these laws.

Recording a call

Use the One Touch Recording (OTR) feature to record a malicious call on your voice mail system. This feature is available only if your administrator has set up the feature on your telephone.

-
1. During an active call, scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to OTR and press **OK** or just press the corresponding line button to start recording the call.

 **Important:**

Some countries, states, and localities have laws that determine if and under what circumstances you can record telephone conversations. Before using the OTR feature, you must understand and comply with these laws.

3. Hang up to stop recording.
-

Making a priority call

Use the Priority Calling feature to provide a special type of call alerting between internal telephone users, including the attendant. The called party hears a distinctive ringing when the calling party uses Priority Calling.

-
1. Before dialing, scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Priority Call and press **OK** or just press the corresponding line button.
 3. Enter the extension you want to call.
 4. Press **Enter** or **OK** to immediately start dialing the priority call to that extension, where the call appearance will show the incoming call as a priority call.
-

Interrupting a call with a whisper page

Use the Whisper Page feature to interrupt or “barge in” on another user’s call and make an announcement. This feature is unique because only the person on the paged extension can hear the page. Other parties on the call cannot hear the page, and the person who makes the page cannot hear anyone on the call. If the paged user has a display telephone, the paged user can see your caller ID. For example, users A and B are on a call. You have an urgent message for user A and make a whisper page. All three users hear the tone that signals the page, but only user A hears the page itself. You cannot hear user B.

-
1. Scroll right from the Phone screen to access the Features menu.
 2. If necessary, scroll down to Whisper Page and press **OK** or just press the corresponding line button .
 3. Enter the extension you want to call.
 4. Press **Enter** or **OK** to immediately start dialing and deliver your message when the person you called answers.
-

Configuring simultaneous ringing for multiple telephones (EC500)

The EC500 feature allows you to have incoming calls to your desk phone ring on your office telephone and your cell phone at the same time. This allows you to answer office calls while you are away from your desk. The cell phone number is programmed by your system administrator.

-
1. From the Phone screen, scroll right to access the Features menu.
 2. Select EC 500.
 3. Press **OK** to turn simultaneous ringing on or off.
-

Extending a call to your cell phone (EC500)

The Extend Call feature allows you to “extend” a call that is active on your office phone to your cell phone using EC500 Extension to Cellular. This allows you to transfer an office call to your cell phone and move away from your desk. This feature is programmed by your system administrator.

 **Note:**

Your system administrator sets the destination telephone number.

Chapter 12: Limited access during failover

One or more telephone system servers provide your phone with its connectivity, features, and functionality. If a disconnect or switch from one server to another occurs, your phone goes into "failover" mode to keep it operating while alternate server resources are established. Depending on the server your phone is on, a [Failover icon](#) may appear on the top display line to notify you that failover is in effect.

Failover has different stages. For example, while your phone transitions to a new server it is in "limbo" and functionality may be limited. Then when the alternate server is active, your phone assumes the functionality available on that server, which may not be the same as your original server. When the original server is restored, your phone transitions back (failback) and functionality may again be limited during the transition. When your phone is back on the original server, normal functionality is restored. Failover and failback are automatic; you have no control over failure mode.

Keep in mind that during failover certain features may not be available and telephone functionality may be limited. Check the softkeys at the bottom of the display to determine the actions you can take during failover; also try the **Phone** button to display the **Home** screen for possible actions.

Important:

Do not log your telephone off during failover or until normal service is restored on your original telephone server. Logging off during failover, during transition to or from an alternate server, or while your phone is active on an alternate server may cause your phone to become inoperable.

The following conditions apply when your telephone is in failover mode:

- Messages like "Acquiring service (if telephone registration hasn't completed)," "Link recovery," "Limited phone service," and "Calls may be lost" may inform you of a failover situation.
- If you are on a call when failover occurs, that call will remain active. You cannot initiate new calls while your phone transitions to the alternate server.
- Certain softkeys may not display and their related functions may be unavailable until transition to the alternate server is complete.
- Call connection may take longer than usual.
- During the transition to a new server, any active conference calls, call transfers, and held calls may be dropped. Incoming calls may not reach you; such calls may go to voice mail.
- Emergency calls may or may not work, depending on the stage of failover and the functionality available on the alternate server.
- Once the transition to a new server has occurred, bridged call appearances are available. Despite a "Log Bridged Calls" option setting of yes, bridged calls are not logged during failover but are available once the phone transitions to the alternate server.
- The Message Waiting Indicator is cleared, but voice mail may still be available if the voice mail server to which calls are being sent is not in failover.

- Once the transition to a new server has occurred, advanced features like Call Park/Unpark, Priority Call, or Automatic Callback may be available. Favorite features are not available during failover but should be available after transition to the alternate server, depending on your system's failover structure.
- Autodial numbers are available on the System Numbers screen during failover.
- If your phone operates under the latest software, changes to Options & Settings can be made/saved. Note that any new or changed settings for these options may not become effective until the phone transitions to the alternate server or fails back to its original server.
- If your phone operates under the latest software, Contacts can be accessed and changed during failover to the alternate server. However, contact changes and new entries are limited to no more than 25 and only one change to a specific contact is allowed. Also, contact searches may be limited; in this case the message "Limited Search results available" displays.
- Once the transition to a new server has occurred, if you are part of a corporate Directory or database, access may be limited to local contacts only.
- You can press the **Phone** button to access Browser Web links/pages during failover (if normally available), however, any "click to dial" links will not work until the phone transitions to the alternate server.
- Transitions back to the normal server will restore all original functionality.

Chapter 13: About locking and logging in to and out of your telephone

Logging in and out maintains your preferences, call information, and options if you share a telephone with other users. Lock your phone or log out to prevent unauthorized use of your telephone during an absence.

Logging in to your telephone extension

Log in from the initial screen when it prompts you for your Username. Depending on your telephone system, certain telephones allow you to log in and use another person's phone as a "visiting user." When you are logged in to another phone as a visiting user, a preset timer may terminate your login after a predetermined period of inactivity. When you log in to another phone as a visiting user, your "home" phone becomes inactive for all but emergency calls and displays a message indicating you are logged in at a different phone.

-
1. Enter the extension number your system administrator has assigned to you for login.
 2. Scroll down to Password.
 3. Enter the password your system administrator has assigned to you.
 4. If your system is set up to allow visiting user privileges, use the right or left navigation arrow to indicate whether you are this phone's primary user (Yes) or whether you are a visiting user of this phone (No).
 5. Press **Enter** or **OK**.
-

Locking and unlocking your telephone

Locking your phone when it is idle prevents it from being used to make a call, with the exception of an emergency call. When locked, a padlock symbol displays and the only actions you can take are to receive calls, make an emergency call, or unlock the phone. Locking your phone does not log it out; you are still logged in but must enter your login password when you unlock the phone. If you press a button that is not allowed on a locked phone, an error beep sounds.

1. If the Phone screen is not displayed, press **Phone**. To lock the phone, be sure no calls are in progress. Alternately, on the Feature menu, select **Phone Lock**.

 **Note:**

Complete any active calls or other telephone functions before attempting to lock the phone.

2. Press the **Lock** softkey.
 3. To unlock your phone, press the **Unlock** softkey and enter the password you use for telephone login.
-

Logging out of your telephone extension

-
1. Press **Avaya Menu**.
 2. Scroll down and select Log Out.
 - 3.
-

Index

A	
access	
limited during failover	65
Active calls	
directing to cell phone	63
Administrative messages	
about	13
AGC	25
applications	
contacts	43
audio path	
on-hook	19
Auto intercom call	56
auto-answer	19
Autodialing	
calling a person	32
setting up	55
automatic call back	56
Avaya Menu	
about	15
options	15
<hr/>	
B	
bridged call appearance	
about	41
joining	41
Bridged Calls	
answering	41
Bridging	42
busy indicator	55
button click sounds	
configuring	23
Button labels	
personalizing	20
Button labels, restoring to default labels	20
<hr/>	
C	
call	61
Call back	56
call history log	
about	47
Call history, calling from	34
Call parking	58
Call pickup	60
Call Timers	
displaying	17
Call unparking	58
Call, Bridged	
transferring to its voice mail	42
calling	
using a click to dial link	35
Calling a number	
using Autodial	32
calling a person	
from the contacts list	33
using speed dial	32
calling intercom group	60
calling using intercom	60
Calling using intercom	56
click to dial	
making a call using	35
conference calls	
about	39
putting a call on hold	40
setting up	39
Conference Calls	
adding a person on hold	39
dropping a person	40
contacts	
about	43
adding from call history	48
calling a person	33
deleting	45
editing	45
searching	43
selecting	43
Contacts	
adding a new	44
coverage	37
<hr/>	
D	
Dial intercom call	60
Dialing Options	
setting	19
Directed call pickup	59
Directory	
searching	34
Directory, calling from	34
Disconnects	

about	65
display	
adjusting contrast	21
Display more	11

E

EC500	
Extend Call	63
Edit dialing	19 , 33
Emergency call	31
error tones	
turning off	23
Excluding others from bridging	42
exclusion	42
Extension	
blocking display of	57
unblocking display of	58

F

failover	65
Feature abbreviations	53
Feature table	53
Features	
about	53
accessing	53
forwarding	
a call	37
turning off	38
Forwarding	
a call	57
Forwarding calls	
about	37

H

Handset	25
Headset	25
History clearing all call entries	48
History, calling from	34
History, of calls	47
History, removing a call from	48
History, turning off	49
History, viewing call details	47
History, viewing for calls	47
hold	
conference calls	40

I

Icons in telephone display	
----------------------------	--

about	12
Incoming call	
ignoring	28
incoming calls	
directing to multiple telephones	62
forwarding	37
sending to coverage	37
transferring	29
Incoming calls	
answering	27
Incoming Calls	
forwarding when busy or no answer	57
Intercom group	60

L

Language	
changing	24
legal notices	2
Locking the phone	67
Logging in to your telephone	67
logging in to your telephone extension	67
Logging out of your telephone extension	67

M

malicious call tracing	60
messages	
getting	51
Messages	
about	13
monitoring other extensions	55
muting calls	28

N

navigation arrows	
right and left	11
up and down	11
Network information	
viewing	13

O

On-hook dialing	19
Options & Settings	
about	15
changing language	24
changing ring pattern	22
configuring visual alerts	18

go to phone screen on ringing	17	Ring Pattern	
phone screen on calling	16	changing	22
redial settings	18	Ring tone	
Setting Autodial numbers	55	setting for call pickup	22
setting call pickup ring tone	22	S	
Setting dialing options	19	scrolling and navigation	
Setting speed dial numbers	20	about	11
Options & Settingscall history	49	SENDALL	37
outgoing calls		Speaker	25
making a call	31	speed dialing	
making a call on a bridged line	42	calling a person	32
redialing a number	32	Speed Dialing	
Outgoing Calls		setting up	20
blocking extension display	57	T	
edit dialing a number	33	Telephone display icons	
unblocking extension display	58	about	12
<hr/>		Telephone stand	
P		about	13
page	62	Time format	24
Parking calls	58	tracing calls	60 , 61
Phone Screen on ringing		Transfer	29
setting	17	U	
Phone Screen Options on calling		Unlocking the phone	67
setting	16	Unparking calls	58
Phone Settings		V	
about	15	Visiting user, logging in as	67
Picking up calls	59 , 60	Visual Alerts	
Presence Icons	12	configuring	18
Priority Call	61	voice mail	
problems with telephone	65	sending an incoming call	27
<hr/>		Voice mail	
R		logging in	51
recording a call	61	Voice Mail, transferring bridged call to	42
redial	32	W	
redial options		Whisper page	62
setting	18		

